



Instructions manual

# TCZR036 TCZR072

8X Bi-Telecentric zoom lenses with motorized control

## Table of contents

1. Product overview .....	pag. 3
2. Safety warnings .....	pag. 3
3. Warranty .....	pag. 4
4. Specifications .....	pag. 4
4.1 Electrical and Electronics Specifications	
4.2 Working Conditions	
5. Instructions for use .....	pag. 5
5.1 Clamping, turning on and focusing	
5.2 How to change magnification	
5.2.1 Magnification change by pressing the button	
5.2.2 Magnification change by DLL	
5.2.3 Alarms, errors and solutions	
5.2.4 Visual error indicators	
6. Software demo .....	pag. 13
6.1 DEMO mode Control Panel	
7. Center position repeatability.....	pag. 15
8. Center displacement.....	pag. 15

## 1. Product overview

TCZR036 and TCZR072 are zoom lenses that provide up to four different magnification changes. In particular, TCZR036 and TCZR072 are varifocal lenses, performing discrete (non-continuous) magnification changes while working at the same fixed working F-number.

## 2. Safety warnings

- ➔ **Read carefully this instructions manual**  
This document contains the necessary information to use the product properly.
- ➔ **Do not inspect the internal parts of the product. Warranty will not be valid if product is opened**  
Zoom revolver contains very delicate components that might be permanently damaged if handled carelessly.
- ➔ **Product must be adequately shielded if employed in dusty and humid places**
- ➔ **Do not use together with machines that generate strong vibrations**  
Zoom Revolver might be permanently damaged if deployed in the presence of strong vibrations and impulsive forces
- ➔ **TCZR must be properly clamped before usage**  
Zoom Revolver must be mechanically constrained by adequate clamps, specifically where indicated (see Mechanical Specifications)
- ➔ **Do not use the product out of the fields of usage marked in the specifications**  
See paragraph 4 for the Specifications.


## 3. Warranty

Opto Engineering offers 100,000 magnification changes as warranty for products that have been installed according to the installation instructions supplied. The product will be either replaced or repaired in case of defects presence in any component. Warranty does not cover parts damaged as a result of incorrect usage.

## 4. Specifications

### 4.1 Electrical and Electronics Specifications

- Input voltage:  $24V \pm 2\%$ ;
- Power consumption: 10 W;
- Electrical cable COCB243P0600 provided;
- TCZR can be connected to PC via USB 2.0 (cable COCBUSB20 provided).  
Connect the standard-A plug end of the cable to the PC and the mini-B plug end of the cable to the Zoom Revolver.



### 4.2 Working Conditions


- Temperature range: 0-60 °C;
- The product must be shielded from vibration sources and impulse forces

## 5. Instructions for use

### 5.1 Clamping, turning on and focusing

The TCZR must be mounted on a rigid support by means of adequate clamps. Specifically it must be constrained in the spaces labelled as “clamping diameter”. Clamping the product in other positions might seriously damage internal components and alter the overall optical performance.

Use the CMHOTCZR mechanical clamp for safer and accurate mounting. CMHOTCZR also allows greater freedom in mounting.





TCZR must be operated according to the drawing above, using the label “THIS SIDE UP” placed on the carter as a reference.

Turn on the product by connecting the power supply cable to a 24V direct current source. When you turn on the device, it emits a specific acoustic signal (trill / “trillo”) and the first available magnification position is automatically selected.


The device should always emit the characteristic acoustic signal (trill). If this is not the case, please contact the seller.

After clamping, attaching the camera and turning on the device, please follow step by step the focusing procedure explained below:


1. Adjust the WD until it is equal to the WD value **listed on the test report provided with your TCZR**



2. Set the maximum magnification position (see section 5.2) until you reach the maximum magnification position, marked by the rightmost LED;
3. Precisely adjust the mount position by means of adding/removing back focal adjustment spacers until you find the best focusing position.



4. Adjust the phase angle. Once you find the right phase, lock the screws (M2 metric thread)



## 5.2 How to change magnification

TCZR offers two ways to change magnification:

**Stand alone** mode by pressing the button;

**On-line mode** by DLL.

### 5.2.1 Magnification change by pressing the button

When used in “stand alone” mode, TCZR is not connected to a PC: change magnification by simply pressing the blue magnification button located below the LED position indicators. Just press the button until you reach the desired magnification position (the corresponding LED position indicator will show the position): after a few seconds the carousel will rotate until it reaches the selected position and the corresponding LED position indicator will turn green.

In case of failure of the procedure defined above, connect the TCZR to a PC and proceed as described in paragraph 5.2.3.

### 5.2.2 Magnification change by DLL

On-line mode magnification change requires the following system specification:

- 512 MB RAM
- 1.5 MB free hard disk space
- XGA or higher-resolution monitor
- Mouse or other pointing device
- Intel® Pentium® III/M 1.4 GHz Processor minimum
- Operating System 32 bit:
- Microsoft® Windows XP Home or Professional (SP2)
- Microsoft® Windows Vista (requires Administrator rights)
- Microsoft® Windows 7 (requires Administrator rights)

You additionally need to implement a DLL that resembles the following DLL Function prototypes.



### 5.2.3 Alarms, errors and solutions

In case of failure, TCZR must be connected to a PC in order to visualize the error type.

Once TCZR is connected to the PC, call the \*GetState function to get the error type. You can subsequently visualize the device state, in particular:

<b>Position</b>	return the current position of the device
<b>ErrorOverSupply</b>	return 1 if supply voltage (Vin) is too high, otherwise 0
<b>ErrorUnderSupply</b>	return 1 if supply voltage (Vin) is too low, otherwise 0
<b>ErrorOverCurrent</b>	return 1 if coil current is too high (over I <sub>max</sub> ), otherwise 0
<b>ErrorI2T</b>	return 1 if I2T error, otherwise 0
<b>ErrorPosition</b>	return 1 if position not reached, otherwise 0
<b>WarningPosition</b>	return 1 if position reached with more steps than StepPulse, otherwise 0
<b>StepDone</b>	return to the steps performed to reach the position
<b>Busy</b>	return 1 if the device is busy, otherwise 0
<b>Run</b>	return 1 if the device is moving, otherwise 0

In case of:


- ErrorOverSupply**
- ErrorUnderSupply**
- ErrorOverCurrent**

Adjust the system’s power supply. If that is not the cause of the failure, contact the seller.

State **ErrorI2T** is a self-protective condition of the system: the device stops working and then automatically re-starts after a certain amount of time. In case of **ErrorI2T** keep monitoring error state and wait for system recovery. Contact the seller if the system does not re-start correctly.

In case of ErrorPosition call the DLL \*Trillo or reboot the system. If the problem persists contact the seller.

### 5.2.4 Visual indicators





```
// DLL Function prototypes -----
-----

// Start communication -----
----
//
// Parameters:
// PortNumber: Serial port number 1 = COM1 , 2 = COM2 etc.. etc.. max 99
// Baud      : Baud 1200,2400,4800,9600,19200,38400,57600,115200
//
// Return value: 0 = ok, -1 = error
int (__stdcall *InitComm)(int PortNumber,int Baud) ;

// -----
----

// Close communication -----
----
//
// Parameters  : none
//
// Return value: none
//
void (__stdcall *CloseComm)(void) ;

// -----
----

// Return the DLL
version-----
//
// Parameters: none
//
// Return value: pointer to the version string
//
char * (__stdcall *GetDllVersion)(void) ;

// -----
----

// Set the timeout for a command response -----
----
//
// Parameters  : timeout in ms (value > 0 and <= 5000) default 500 ms
//
// Return value: 0 = OK, -1 = value <= 0, -2 = value > 5000
//
int (__stdcall *SetTimeOutRxCommand)(int milliseconds) ;

// -----
----

// Return the firmware version -----
----
//
```

```

// Parameters:
//
// Version      : pointer to the string which contains the version (minimum
size 10 bytes)
//
// Return value: 0 = Ok ; -1 = timeout error; -2 = Checksum error , -3 =
serial communication not started (InitComm)
//
int (__stdcall *GetFwVersion)(char *Version) ;

// -----
// -----

// Return the device status -----
// -----
//
// Parameters:

// Position      : return the current position of the device
// ErrorOverSupply : return 1 if supply voltage (Vin) is too high,
otherwise 0
// ErrorUnderSupply : return 1 if supply voltage (Vin) is too low,
otherwise 0
// ErrorOverCurrent : return 1 if coil current is too high (over Imax),
otherwise 0
// ErrorI2T      : return 1 if I2T error, otherwise 0
// ErrorPosition  : return 1 if position not reached, otherwise 0
// WarningPosition : return 1 if position reached with more steps than
StepPulse, otherwise 0
// StepDone      : return to the steps performed to reach the
position
// Busy          : return 1 if the device is busy, otherwise 0
// Run           : return 1 if the device is moving, otherwise 0
//
//
// Return value: 0 = Ok ; -1 = timeout error ; -2 = Checksum error ; -3 =
serial communication not started (InitComm)
//
int (__stdcall *GetState)(char unsigned *Position,char unsigned
*ErrorOverSupply,
                        char unsigned *ErrorUnderSupply,char unsigned
*ErrorOverCurrent,
                        char unsigned *ErrorI2T,char unsigned
*ErrorPosition,
                        char unsigned *WarningPosition,char unsigned
*StepDone,
                        char unsigned *Busy,char unsigned *Run) ;

// -----
// -----

// Read working parameters stored in the device -----
// -----

```

```
//
// Parameters:
//
// T1          : 0 .. 10000 ms |
// T2          : 0 .. 10000 ms | <- Pulse
// T3          : 0 .. 10000 ms |
// TDuty       : 0 .. 2       | (0 = 25%, 1 = 50%, 2 = 75%)

// TT1        : 0 .. 10000 ms |
// TT2        : 0 .. 10000 ms | <- special pulse (Trillo)
// TT3        : 0 .. 10000 ms |
// TTDuty     : 0 .. 2       | (0 = 25%, 1 = 50%, 2 = 75%)

// I2Tmax     : 0 .. 1000000   Thermal image limit
// VinMin     : 0 .. 60000 mV  minimum input voltage
// VinMax     : 0 .. 60000 mV  maximum input voltage
// Imax       : 0 .. 60000 mA  maximum current
// StepPulse  : 0 .. 200      pulses needed to move to a position
(step)
// ExtraPulse : 0 .. 200      Extra pulses
//
// Return value: 0 = 0k ; -1 = timeout error; -2 = Checksum error ; -3 =
serial communication not started (InitComm)
//

int (__stdcall *GetParameters)(int *T1,int *T2,int *T3,int *TDuty,int
*TT1,int *TT2,int *TT3,int *TTDuty,int *I2Tmax,int *VinMin,int *VinMax,int
*Imax,int *StepPulse,int *ExtraPulse) ;

// -----
// -----

// Move command -----
// -----
//
// Parameters:
//
// Position   : 0 .. 3 possible positions of the device
//
// Return value: 0 = 0k, -1 = timeout error; -2 = Checksum error , -3 =
NAK device busy; -4 = serial communication is not open (InitComm)
//

int (__stdcall *GoToPosition)(int position) ;

// -----
// -----

// Trillo command (special pulse) -----
// -----
//
// Parameters: none
//
//
// Return value: 0 = 0k, -1 = timeout error; -2 = Checksum error ; -3 =
```

```
NAK device busy; -4 = serial communication is not open (InitComm)
//
int (__stdcall *Trillo)(void) ;
// -----
// Functions for debugging purposes -----
// Return the pointer to the transmit buffer (for debugging)
char * (__stdcall *DebugBufferTx)(void) ;
// Return the pointer to the receive buffer (for debugging)
char * (__stdcall *DebugBufferRx)(void) ;
// -----
```

## 6. Software demo

Together with your TCZR, you additionally get the demo software “test DLL”. System requirements for installing the demo software are the following:

- 512 MB RAM;
- 1.5 MB free hard disk space;
- XGA or higher-resolution monitor;
- Mouse or other pointing device;
- Intel® Pentium® III/M 1.4 GHz processor minimum;
- Operating Systems 32 bit:
  - Microsoft® Windows XP Home or Professional (SP2);
  - Microsoft® Windows Vista (requires Administrator rights);
  - Microsoft® Windows 7 (requires Administrator rights).

Run the executable file (setup.exe) to start software installation.

### 6.1 DEMO mode Control Panel

TCZR control panel consists of 5 sections:

- Ports
- Parameters
- Versions
- Device Status
- Commands

In section Ports press the OPEN button to connect your TCZR to the PC. The “Common Port” window shows the virtual serial port number where the device is found. Three state coloured indicators show state messages: the system is correctly connected if the Connected indicator turns green while Timeout and Checksum are error messages.

In section Parameters, the default factory settings are listed. Press the “GET” button to update and get the present values.


Section Versions lists the DLL release and firmware version.

In the Device Status Section, the following error, warning and state indicators are listed.

In detail:

1. Over supply error (see 5.2.3);
2. Under supply error (see 5.2.3);
3. Over current error (see 5.2.3);
4. I2T error
5. Position Error (see 5.2.3);
6. Position warning (see 5.2.3);
7. Busy (see 5.2.3);
8. Run (see 5.2.3).

Commands section allows the user to set the Zoom Revolver magnification by selecting the corresponding position (0,1,2,3). In case of position Error, press the “Trillo” button to recover the position.




You can download the complete software package from this location:

[www.opto-engineering.com/products/tcZR#downloads](http://www.opto-engineering.com/products/tcZR#downloads)

## 7. Center position repeatability

Center position repeatability is defined as the positional stability of a reference point at the same magnification, keeping the same measurement configuration.

Choosing a reference point  $C_1 (X_1; Y_1)$ , after  $n$  measurements at the same magnification, the distribution of reference point positions  $(C_1, C_2, \dots, C_n)$  has a mean  $C_m (X_m; Y_m)$  that is the Center of the repeatability area. The radius of this area is the maximum distance between the mean of the distribution and any other reference point registered in testing.




## 8. Center displacement

Every zoom system shows different image centering at different magnification settings.

Choosing a reference point at a given magnification, when magnification is changed this point shifts. The maximum distance between reference points at different magnifications is center displacement.


To better understand this effect you can refer to the following picture.



To eliminate this effect you can select a reference point at the image center when the lens is set at its maximum magnification. Then you can measure the x and y image center displacements at the other three magnifications.

The x and y (dx and dy) displacements must be recorded together with other calibration parameters specific for each zoom configuration (magnification factor, residual distortion correction parameters...)

The maximum x or y displacement will define the width and height of a crop-window which will show the image center always perfectly aligned.





## CE Conformity

Opto Engineering declares that product TCZR series complies with the provisions of the Community Directive 2004/108/CE (EMC) according to EN 61326-1 (Measuring Devices and Control Laboratory), including all applicable amendments. All standards and/or technical specifications mentioned below have been applied.

Method	Title
CEI EN 61326-1:2007-03	Electrical equipment for measurement, control and laboratory use EMC requirements. Part1: General requirements
CEI EN 61000-4-2:2011-04	Electromagnetic compatibility (EMC) Part 4-2: Testing and measurement techniques - Electrostatic discharge immunity test
CEI EN 61000-4-3:2007-04 CEI EN 61000-4-3/A1:2009-01 CEI EN 61000-4-3/A2:2011-01	Electromagnetic compatibility (EMC) Part 4-3 : Testing and measurement techniques - Radiated, radio-frequency, electromagnetic field immunity Test
CEI EN 61000-4-8:1997-06 CEI EN 61000-4-8/A1:2001-10	Electromagnetic compatibility (EMC) Part 4: Testing and measurement techniques Section 8: Power frequency magnetic field immunity test – Basic EMC Publication

Tests were carried at a certified laboratory.

## Contact us

### EUROPE

---

**Opto Engineering  
Europe headquarters**

Circonvallazione Sud, 15  
46100 Mantova, IT  
phone: +39 0376 699111  
contact@opto-engineering.com

**Opto Engineering  
Germany**

Agnes-Pockels-Bogen, 1  
80992 München, DE  
phone: +49 0 89 18930918  
de@opto-engineering.com

### UNITED STATES

---

**Opto Engineering  
USA**

11261 Richmond Ave  
Ste G-108 - Houston, TX 77082  
phone: +1 832 2129391  
us@opto-engineering.com

### ASIA

---

**Opto Engineering  
China**

Room 2405, n°885, Renmin RD  
Huangpu District 200010  
Shanghai, China  
phone: +86 21 61356711  
info@deepview.cn

**Opto Engineering  
Japan**

*official partner*  
Optart Corporation  
4-54-5 Kameido Koto-ku  
Tokyo, 136-0071 Japan  
phone: +81-3-5628-5116  
jp@opto-engineering.com

**Opto Engineering  
Korea**

*official partner*  
Far Island Corporation, Ltd.  
Seoul, Korea  
phone: +82 70 767 86098  
+82 10 396 86098  
kr@opto-engineering.com